

Accessories

JH series

adjustment aids

Features

- Adjustment for positioning cameras perpendicular to test objects
- Fast adjustment
- Adjustment is carried out by aligning two sets of crosshairs

Adjustment aids only function over the entire field of view of the camera in conjunction with telecentric lenses. If entocentric lenses used, the adjustment aids can only be used in the exact centre of the image.



Notes

Properties

Base area: 39 mm diameter
Height: 21 mm
For incident and backlight uses



Accessories

JH series

adjustment aids

Optical data

Name	Order no.	Distance between crosshairs [mm]	Recommended for lenses with lateral magnification
JH 5	5-10-111	5	< -0,7 ... -0,5
JH 10	5-10-112	10	< -0,5 ... -0,2
JH 20	5-10-114	20	< -0,2 ... -0,1
JH 2,7	5-10-110	2,7	< -1,2 ... -0,7